



Parts - Pièces


Base Assembly (04995)




Drive Pad



Handle Assembly (04973)



Switch Box DS Cover Assembly (04193)



19935
Integra LA DS 19"

Base Assembly (04995)

Part N.	Description	Quantity
01096	10-24 x 1/2" Phillips Screw	2
03016	5/16 Lockwasher	4
03063	1/2" Nylon Washer	4
03163	5/16" Flat Washer	4
03935	1 1/2 HP DC Motor c/w Gearbox 11:1	1
03945	5" Wheel	2
04103	Handle Brace	1
04105	Axle Shaft	1
04112	Axle end cap	4
04113	5/16- 18 X 1 1/2" Bolt	4
04184	Indicator Light	1
04213	Water Hole Plug	1
04900	Chassis 19"	1
04905	1/4-20 X 3/4" Phillips Screw	2
04906	1/4" Washer	2
04921	Bumper 19"	1
04944	T-Support Axle	1
04947	Motor Cover	1
20060	1/2" Tension Washer	2
20139	Foam Shroud	1

Switch Box DS Cover Assembly (04193)

Part N.	Description	Quantity
03699	1 1/2 HP Micro Switch	1
03954	6/32 x 1/4" Phillips Screw	2
04133	Switch Box Cover	1
04163	Hi-Low Switch	1
04166	8-32 X 1/4" Phillips Screw	4
04169	6-32 X 7/8" Phillips Screw	2
04340	Speed Control	1
04366	Lead Wire	1
20031	Internal Lock Washer	2

Handle Assembly (04973)

Part N.	Description	Quantity
01372	Power Cord 50' / 15.24M	1
01640	Locking Handle c/w 04147 Plug	1
01745	Pigtail 42"	1
03789	Foam Handle Grip	2
03949	Safety Switch Knob	2
03951	Safety Switch Spring	1
04131	Switch Box	1
04155	Cable Spring	1
04173	3/8" Grommet	1
04177	Handle Tube	1
04179	#14-1 1/2" Flat head Screw	2
04190	8-32 X 1/2" Phillips Screw	4
04198	Handle Tube Plug	2
04199	8-32 X 1/4" Phillips Screw	3
04248	1/4-20 X 3/4" Bolt	2
04909	Trigger	1
04910	Safety Switch Lever	1
04933	Chrome handle Tube	1
04942	Cord Hook Clamp	1
20002	1/4"-20 Nylon Lock Nut	2
20484	Cord Grip	2

Drive Pad

Part N.	Description	Quantity
04382	Clutch Plate c/w Screws (6)	1
40278	Standard Drive Pad 18"	1
42106	Red Buffing Pad 19" (5/cs)	.2

Optional Spare Parts

Part N.	Description	Quantity
03847	Carbon brush 4 per Set	1
03865	Rectifier	1