Victory Backpack Sprayer Cordless Electrostatic Sprayer with Tank



Applications:

To use the Victory Sprayer, first charge the battery by inserting it into the charger and plugging the charger into a wall socket. Next, unlatch tank lock from backpack by lifting upward and outward from backpack base. Fill tank with solution before inserting tank back into backpack housing. Insert the charged battery into the battery socket and lock in place. Pull the trigger and spray on your desired surface.

Benefits:

- Ideal for disinfecting, sanitizing, and odour removal
- Uses less solution
- Touchless application
- Reduces cross-contamination
- · Designed to meet dwell time
- Cordless convenience allows for effortless movement room to room
- Easy to implement & cost effective

Codes:

Product Code: 72001

• UPC: 0 56069 72001 4

Sprayer Specifications:

Colour	Green	
System	Electrostatic	
Power	Cordless	
Tank Size	2.25 Gal (8.5 L)	
Optimum Spray Range	4 - 6 ft	

Nozzle Specifications

		\bigcirc
Setting 1	Setting 2	Setting 3
Full Cone	Full Cone	120° Fan
40 microns	80 microns	110 microns
3 - 5 minutes	8 - 10 minutes	+ 10 minutes
3.4 oz/min	5.1 oz/min	13.4 oz/min
84 min	56.5 min	21.8 min
23,000 ft ²	20,600 ft ²	13,100 ft ²
2.9	4.2	11
	Full Cone 40 microns 3 - 5 minutes 3.4 oz/min 84 min 23,000 ft²	Full Cone 40 microns 80 microns 3 - 5 minutes 8 - 10 minutes 5.1 oz/min 84 min 56.5 min 23,000 ft² 20,600 ft²

Dustbane is an authorized distributor of:



Compatible Format: Packaging:

Sprayer: 13" x 8" x 22" (33 x 20 x 56 cm)

10.0 lbs (4.5 kg) – Empty 28.8 lbs (13.1 kg) – Full

Box: 17.75" x 10" x 23.5" (45 x 25 x 60 cm)

16 lbs (7.25 kg) 1 per case

